



































Installation & Handling Procedures Working with Aggregate • PaveMend™ does not require the use of aggregate extenders • Generally, other products require aggregate extenders due to excessive heat generation when those materials are used to depths of 1-2 inches or more • PaveMend™ can be poured onto an aggregate bed. It will penetrate 1-2 inches before solidifying







